



OWNER'S MANUAL
PART IDENTIFICATION
2565-971_REV_C 03/2026



YETTER MANUFACTURING CO.

Founded 1930

Colchester, IL 62326

Toll free: (800)447-5777.

Fax: (309)776-3222

Website: yetterco.com

E-mail: info@yetterco.com

YETTER

FOREWORD

You've just joined an exclusive but rapidly growing club.

For our part, we want to welcome you to the group and thank you for buying a Yetter product.

We hope your new Yetter products will help you achieve both goals-increase your productivity and increase your efficiency so that you may generate more profit.

This operator's manual has been designed into four major sections: Foreword, Safety Precautions, Installation Instructions and Parts Breakdown.



This **SAFETY ALERT SYMBOL** indicates important safety messages in the manual.

When you see this symbol, be alert to the possibility of **PERSONAL INJURY** and carefully read the message that follows.

DANGER: Indicates an imminently hazardous situation which, if not avoided "will" result in death or serious injury. This signal word is to be limited to the most extreme situations

WARNING: Indicates a potentially hazardous situation which, if not avoided, "could" result in death or serious injury.

CAUTION: Indicates a potentially hazardous situation, which if not avoided, "may" result in minor or moderate injury. It may also be used to alert against unsafe practices.

NOTICE: Indicates information considered important, but not hazard related (e.g., messages relating to property damage).

correct operating procedure and to lubricate and maintain the product according to the maintenance schedule in the operator's manual.

Important will apply to the same information as specified by note only of an immediate and urgent nature.

It is the responsibility of the user to read the operator's manual and comply with the safe and correct operating procedure and to lubricate and maintain the product according to the maintenance schedule in the operator's manual.

The user is responsible for inspecting his machine and for having parts repaired or replaced when continued use of the product would cause damage or excessive wear to the other parts.

It is the user's responsibility to deliver his machine to the Yetter dealer who sold him the product for service or replacement of defective parts, which are covered by the warranty policy.

If you are unable to understand or follow the instructions provided in this publication, consult your local Yetter dealer or contact:

YETTER MANUFACTURING CO.

309/776-4111

800/447-5777

309/776-3222 (FAX)

Website: www.yetterco.com

E-mail: info@yetterco.com

WARRANTY

Yetter Manufacturing warrants all products manufactured and sold by it against defects in material. This warranty being expressly limited to replacement at the factory of such parts or products as shall appear to be defective after inspection. This warranty does not obligate the Company to bear cost of labor in replacement of parts. It is the policy of the Company to make improvements without incurring obligations to add them to any unit already sold. No warranty is made or authorized to be made, other than herein set forth. This warranty is in effect for one year after purchase.

DEALER: _____

Yetter Manufacturing warrants its own products only and cannot be responsible for damages to equipment on which mounted.



SAFETY PRECAUTIONS

A brief description of signal words that may be used in this manual:

DANGER: Indicates an imminently hazardous situation which, if not avoided “will” result in death or serious injury. This signal word is to be limited to the most extreme situations.

WARNING: Indicates a potentially hazardous situation which, if not avoided, “could” result in death or serious injury.

CAUTION: Indicates a potentially hazardous situation, which if not avoided, “may” result in minor or moderate injury. It may also be used to alert against unsafe practices.

NOTICE: Indicates information considered important, but not hazard related (e.g., messages relating to property damage).

Consult your implement and tractor operator’s manual for correct and safe operating practices. Be aware of towed implement width and allow safe clearance.

Safety decals are placed on the implement to alert the operator and others to the risk of personal injury or unsafe operation during normal operations and servicing.

1. The safety decals must be kept clean and in good condition to ensure that they are legible.
2. Safety decals must be replaced if they are missing or illegible.
3. When components are replaced during repair or servicing, check that the new components include the necessary safety signs.
4. Replacement safety decals may be obtained from your local dealer.



WARNING

Read these instructions carefully to acquaint yourself with the Equipment. Working with unfamiliar equipment can lead to accidents.

Never park the equipment on a steep incline or leave the equipment running unattended.

Never clean, lubricate or adjust a machine that is in motion.

Always check that straps are secure.

Make sure latches are in pinned position when moving equipment.

Do not allow children to operate this equipment.

Do not allow riders on the equipment, trailer and/or pick-up.

Use speed and caution dictated by the terrain being traversed. Do not operate on any slope steep enough to cause tipping or loss of control.

Read and understand the operator’s manual and require all other persons who will operate the equipment to do the same.

If operating on public roadways, where legal, be certain all lighting is operating properly and observe all traffic laws.

Beware of increased stopping distances and control effort when operating with implements attached.

Be familiar with all controls and be prepared to stop equipment quickly in an emergency.

FAILURE TO HEED MAY RESULT IN PERSONAL INJURY OR DEATH.

TABLE OF CONTENTS

FOREWORD.....	2
SAFETY.....	3
BOLT TORQUE.....	4
INSTALLATION.....	5-6
OPERATION.....	7-8
PARTS IDENTIFICATION.....	6, 9-14

BOLT TORQUE





NOTICE: Over-tightening hardware can cause just as much damage as under-tightening. Tightening hardware beyond the recommended range can reduce its shock load capacity.

All hardware is either Grade 5 unless otherwise noted. Grade 5 cap screws are marked with three radial lines on the head. Grade 8 cap screws are marked with six radial lines on the head. If hardware must be replaced, be sure to replace it with hardware of equal size, strength and thread type. Refer to the torque values chart when tightening hardware.

The chart below is a guide for proper torque. Use it unless a specified torque is called out elsewhere in the manual. Torque is the force applied to the end of the handle or cheater bar, times the length of the handle or bar. Tightening hardware beyond the recommended range can reduce its shock load capacity.

Use a torque wrench wherever possible

The following table shows torque in ft.-lbs. for coarse thread hardware.

Bolt Diameter and Threads per Inch	 Grade 2	 Grade 5	 A-325	 Grade 8
1/4	6	10		14
5/16	12	20		30
3/8 – 16	25	35		50
7/16 – 14	35	55		80
1/2 – 13	55	85		125
9/16 – 12	75	125		175
5/8 – 11	105	170		235
3/4-10	185	305		425
7/8 – 9	170	445		690
1-8	260	670		1030
1 1/8 – 7	365	900		1460
1 1/4 - 7	515	1275		2060
1 3/8 – 6	675	1675		2700
1 1/2 - 6	900	2150		3500
1 3/4 – 5	1410	3500		5600


3800 SERIES

SAFETY EQUIPMENT ASSEMBLY

SAFETY LIGHTING



NOTICE: Attach safety lighting to the toolbar frame, install the wiring harness and secure to the frame with the cable ties.



SMV ASSEMBLY

1. Mount SMV emblem as shown with point of triangle up as near operators left of center as possible. Face so emblem is visible from rear of equipment.




NOTICE: Be sure to purge the air from the hydraulic cylinders. This insures smooth wing operation.

WARNING STAND CLEAR OF FOLDING WINGS



ASSEMBLY



ITEM	PART NO.	DESCRIPTION	QTY
1	1300-446	HARNESS, COMMON WIRING	1
2	2502-105	1/4-20 X 3/4 HHCS GR 5 ZP	2
3	2502-293	1/2-13 X 1-1/4 HHCS GR5 ZP	2
4	2505-402	5/8-11 X 2" CAR. BLT. GR.5 ZP.	4
5	2515-172	CYLINDER CLEVIS PIN, ZP	2
6	2515-326	TEE, -6 / -6 / -6 JIC	2
7	2515-327	ADAPTOR, 3/4-16 SAE TO -6 JIC (6400-06-08)	2
8	2515-330	90 DEG., 3/4 SAE TO -6 JIC	4
9	2515-336	3 X 16 ASAE CYLINDER (SAE)	2
10	2515-357	HOSE, .25 X 40" W/-6 FEMALE JIC ENDS	2
11	2515-359	HOSE, 1/4 X 60" W/-6 JIC ENDS	2
12	2515-363	HOSE, 1/4 X 80" W/-6 JIC ENDS	2
13	2515-405	CABLE TIE, .5" X 40.5", BLACK	18
14	2520-152	1/4-20 LOCK HEX NUT ZP	2
15	2520-361	1/2-13 FLANGE WHZLCK HXNT, GR 5, ZP	2
16	2520-464	5/8-11 WHIZLOCK HEX NUT, GR 2, ZP	10
17	2526-542	1" SAE FLAT WASHER ZP	8
18	2530-108	3/16 X 1-1/2 ROLL PIN ZP	4
19	2530-157	1/4 X 1-3/4 ROLL PIN ZP	4
20	2570-472	SMV EMBLEM WITH BACKING	1
21	2570-778	5/8 X 7 X 6 U-BOLT	3
22	3400-227	LIGHT BRACKET W.A., AMBER LAMP	2
23	3400-377	STRAIGHT SMV BRACKET	1
24	3800-120	RED LIGHT BRACKET ASSEMBLY	2
25	3800-121	AMBER LIGHT BRACKET ASSEMBLY, LH	1
26	3800-122	AMBER LIGHT BRACKET ASSEMBLY, RH	1
27	3820-171A	20 FT. FOLDING HEAVY DUTY TOOLBAR ASSEMBLY	1
28	3820-306	CYLINDER CLEVIS PIN	2
29	RE152269	MODULE, IMPLEMENT TURN SIGNAL	1

ATTACHING 3800 TOOLBAR TO TRACTOR



CAUTION: BEFORE ATTACHING TO TRACTOR, BE SURE HITCH PINS ARE COMPLETELY ASSEMBLED TO MATCH YOUR TRACTOR HITCH.



CAUTION: MAKE CERTAIN THAT CENTER LINK AND QUICK COUPLER ARE LOCKED AND LOCK PINS ARE PROPERLY INSTALLED BEFORE MOVING.

Detaching from Tractor



CAUTION: To avoid injury from escaping hydraulic oil under pressure, relieve the pressure in the system before removing hoses from breakaway couplers.

NOTICE: To prevent possible tipping, install parking stands on toolbar before disconnecting from tractor.



FIELD OPERATION

PRE-OPERATION CHECK LIST:

Use this checklist each time you operate the 3800 Toolbar in the field. It will help you obtain satisfactory field operation quickly.

1. Tractor sway blocks in upper position.
2. Center link adjusted for level frame in field operation.
3. Tractor lift links set in lateral float.
4. Hitch pins fastened and correct spacers used.
5. Quick couplers latched.
6. Adequate ballast added to front of tractor.

MAIN FRAME HEIGHT

Without gauge wheels, set the tractor rockshaft control lever to obtain the desired frame height.

LEVELING MAIN FRAME

Adjust lift links and center link as necessary to make frame level and perpendicular to the ground.

Before activating/folding hinge check for obstructions, especially check gauge wheel positions to ascertain proper tractor and cab clearance.

IMPORTANT: If gauge wheels are to be used, make leveling adjustments after gauge wheels are installed.

WING LOCKS

To lock wings rigid, unfold the wings and put collar over the wing lock stud. Then install the pin through the collar and stud to secure.

CAUTION: ALWAYS FOLLOW ALL STATE, FEDERAL, AND LOCAL LAWS WHEN TRANSPORTING 3800 TOOLBAR ON PUBLIC ROADS.




TROUBLE SHOOTING

Problem	Cause	Solution
Hydraulic cylinders fail to operate properly	Hydraulic system improperly installed	Check for correct assembly of the hydraulic system
	Air in system	Check for air in the hydraulic system and purge system
	Blocked restrictors	Check restrictors for malfunctions

PARTS IDENTIFICATION 3820-171


ITEM	PART NO.	DESCRIPTION	QTY
1	2502-240	3/8-16 X 2 CAP SCREW GRADE 5	2
2	2502-251	3/8-16 X 3 CAP SCREW GRADE 8	4

3	2502-333	5/8-11 X 9 CAP SCREW GRADE 5	8
4	2502-770	1-8 X 5 CAP SCREW GRADE 5 (OPTIONAL)	1
5	2520-255	3/8-16 LOCK HEX NUT GRADE 2	6
6	2525-459	5/8-11 LOCK HEX NUT GRADE 5	8
7	2520-555	1-8 HEX NUT (OPTIONAL)	1
8	2525-550	1" LOCKWASHER (OPTIONAL)	1
9	2526-542	1" SAE FLATWASHER	4
10	2530-157	1/4 X 1-3/4 ROLL PIN	4
11	2565-058	YETTER DECAL	10
12	2565-861	FALLING WING DECAL	2
	2565-859	HYDRAULIC SKIN INJECTION WARNING DECAL	2
	2565-860	CHARGE HYDRAULIC SYSTEM WARNING DECAL	2
13	2565-466	PRODUCT ID PLATE	1
14	2570-454	KLIK PIN	3
15	2570-457	LOOP GRIP PIN	2
16	2570-465	7 GAUGE HAIRPIN	4
17	2570-748	BENT PULL PIN	4
18	3400-312	UPPER HITCH SPACER (OPTIONAL) 1.315" OD	1
19	3560-206	UPPER HITCH PIN	1
20	3560-207	LOWER HITCH PIN	2
21	3560-303	UPPER HITCH BUSHING 1.75" OD	1
22	3560-304	BUSHING 2" OD X 1.50" ID X 5.625" LONG	2
23	3815-201	PARKING STAND	2
24	3815-202	STAND LEG	4
25	3815-306	CLAMP STRAP 5"	4
26	3820-200	20" CENTER SECTION	1
27	3820-201	WING LEFT HAND	1
28	3820-202	WING RIGHT HAND	1
29	3820-203	WING UPPER STOP LINK	2
30	3820-204	WING CONNECTING LINK	2
31	3820-300	LOWER LINK PIVOT PIN 1" X 9.125"	2
32	3820-307	WING LINK PIVOT PIN 1" X 6.50"	2
33	3820-310	UPPER LINK PIN 1" X 6.188"	2
34	3820-320	HINGE PIN 1.5" X 19"	2
35	3820-328	WING LOCK BUSHING	2



PARTS IDENTIFICATION 3815-171

ITEM	PART NO.	DESCRIPTION	QTY
1	2502-333	5/8-11 X 9 CAP SCREW GRADE 5	8
2	2502-770	1-8 X 5 CAP SCREW GRADE 5 (OPTIONAL)	1
3	2520-459	5/8-11 LOCK HEX NUT GRADE 5	8
4	2520-555	1-8 HEX NUT (OPTIONAL)	1
5	2525-550	1" LOCKWASHER (OPTIONAL)	1
6	2565-058	YETTER DECAL	4
7	2565-466	PRODUCT ID PLATE	1
8	2565-822	YETTER DECAL	2
9	2570-454	KLIK PIN	3
10	2570-465	7 GAUGE HAIRPIN	4
11	2570-478	PIN	4
12	3400-312	UPPER HITCH SPACER (OPTIONAL) 1.315" OD	1
13	3560-206	UPPER HITCH PIN	1
14	3560-207	LOWER HITCH PIN	2
15	3560-303	UPPER HITCH BUSHING 1.75" OD	1
16	3560-304	BUSHING 2" OD X 1.50" ID X 5.625" LONG	2
17	3815-200	15' RIGID DOUBLE FRAME	1
18	3815-201	PARKING STAND	2
19	3815-202	STAND LEG	4
20	3815-306	CLAMP STRAP 5"	4




PARTS IDENTIFICATION

PARTS IDENTIFICATION

3800-120 RED LIGHT ASSEMBLY





ITEM	PART NO.	DESCRIPTION	QTY.
1	1300-447	LAMP, RED	1
2	2565-459	RED REFLECTOR	1
3	2565-460	NONREFLECTIVE RED-ORANGE FLUORESCENT	1
4	3800-326	LIGHT BRACKET, RED LAMP	1
5	19M7297	M8 X 12MM CAP SCREW GRADE 5	2



PARTS IDENTIFICATION

3800-121 AMBER LIGHT ASSEMBLY, LEFT HAND





ITEM	PART NO.	DESCRIPTION	QTY.
1	1300-448	LAMP, AMBER	1
2	2565-459	RED REFLECTOR	1
3	2565-460	NONREFLECTIVE RED-ORANGE FLUORESCENT	1
4	2565-813	YELLOW REFLECTOR	1
5	3800-327	AMBER LIGHT BRACKET	1



PARTS IDENTIFICATION

3800-122 AMBER LIGHT ASSEMBLY, RIGHT HAND

ITEM	PART NO.	DESCRIPTION	QTY.
1	1300-448	LAMP, AMBER	1
2	2565-459	RED REFLECTOR	1
3	2565-460	NONREFLECTIVE RED-ORANGE FLUORESCENT	1
4	2565-813	YELLOW REFLECTOR	1
5	3800-327	AMBER LIGHT BRACKET	1



NOTES:



A Tradition of Solutions since 1930

Yetter Farm Equipment Co

PO BOX 358 109 S. McDonough

Colchester, IL 62326-0358

Phone: 309-776-4111

Toll Free: 800-447-5777

Email: info@yetterco.com

For updated models and manuals visit the Yetter website:

www.yetterco.com

© Yetter Farm Equipment Co. All Rights Reserved

2565-971_REV_C – 03/2026